

IC720 FlyHawk 2-Place Intercom Instructions:

The two jacks are ICOM Style Connector (IC720) or Standard Straight style connectors (IC720B) that can be used with a dash mounted RF Radio for Receiving and Transmitting. If you have a portable Two Way radio, then you will need the optional jack adapters (not included with intercom) to fit your radio, if it is not an ICOM.

The unit runs on one 9V Alkaline Battery (not included).



SQ: The adjustable MUTE knob (SQUELCH) allows you to automatically turn the unit on when you or a passenger talk into the microphone. Adjust the sensitivity by turning the knob clockwise. Works with mixed headsets of same impedance.

ON/VOLUME: Adjustable volume control. When not in use, turn the volume knob all the way to OFF by rotating counter clockwise.

PTT: (Push To Talk) plug. You can connect a PTT button to this plug.

MIC: Connect headset Microphone jack here.

SP: Connect headset Speaker jack here.

Side Slide switch: Allows either both users to communicate on the radio, or just the pilot.